



BOOT Selection

S2	JTAG	QSPI2M	SD1(2.0)	QSPI
S2A	OFF	ON	OFF	OFF
S2B	OFF	OFF	ON	OFF
S2C	OFF	OFF	OFF	ON
S2D	USER (VERSAL LPD)			

JTAG Selection

S4	Versal	Artix-Versal-Chain
S4A	OFF	ON
S4B	ON	OFF
S4C	OFF	ON
S4D	USER (VERSAL PMC)	

FMC_VADJ Voltage Selection

S5	1.2 V	1.8 V	2.5 V	3.3 V
S5A	OFF	ON	ON	ON
S5B	OFF	OFF	ON	ON
S5C	OFF	OFF	OFF	ON
S5D	USER (ARTIX)			

USB Jumper

Host	<input type="checkbox"/>
Device	<input type="checkbox"/>
OTG	<input type="checkbox"/>

C
777

Trenz Electronic GmbH
Beendorfer Str. 23
32609 Huellhorst
Germany

www.cruvi.com



TE0950-03



SerialID

000000

www.trenz-electronic.de

U0p3
LCC3
LEE2
U0p6
E1r1v
LEE1
LEE0
USER

J18
TP7
TP8
TP10
TP9
Versal
U16
U15
TP14
TP15
U06
TP15

JTAG, UART
U17
TP38
TP41
U48
U46
U49
U48

U29
USB Jumper
J5
S2-BOOT
S4
JTAG
TP13
TP14
U24
U25

U29
U21
U23
U24
U25

J47
TP40
J9
L44
FMC_VADJ
R4
S5
TP20
TP1
TP2B
TP27

TP42
U49

J3

U51
TP45
U6
U7
TP44
TP47
TP46
U52
U50
TP43

U40
U45
TP34
TP38
TP39

L42
U41
U39
U43
TP33
TP35
TP36
TP37

U35
TP23
U37
TP29
TP32
U14
TP30
U38
TP31

TP17
12 V
5 V
3.3 V
U FMC

J1
C_HS2

J10
C_HS1

J12
C_LS1

J13
C_LS2

J15

J17

