



trenz electronic

TEB0912-03



J30

J28

J35

S3

D2 D3 D4 D5

FF_0 J2 TX J1

FF_1 J4 TX J3

FF_2 J6 RX J5

FF_3 J8 RX J7

FF_4 J10 RX J9

FF_5 J12 RX J11

FF_6 J14 TX J13

FF_7 J16 TX J15

S5 RESET

S6 POWER

J40

USR

J29

J31

J27

U79

J37

ETH1

ETH2

J25

J26

WIFI

D14

U74

J41

J17

J19

J21

J23

J24

J18

J20

J22

J24

J18

J20

J22

J24

J18

J20

J22

J24

J18

J20

J22

J24



J36

J32

J33

J38

J34

J39

J38

J34

J39

J38

J34

J39

J38

J34

J39

J38

J34

J39

J38

J34

S2

BOOT

D1

D12

D13

PWR_STAT

J32

J33

J39

J38

J34

J39

J38

J34

J39

J38

J34

J39

J38

J34



CPLD_CFG

BXND22

ADM

+12V

+12V

CON

J39

J38

J34

J39

J38

J34

J39

J38

J34

J39

J38

J34