



trenz
electronic

TEC0330-03



DB4
L3
D1



J2

L8
L9
L10
L11
L12
L7

C197
C198
C199
C200
C203
C205
C206
C196
C195
C194
C193
C192
C191
C190
C189
C188
C187
C186
C185
C184
C183
C182
C181
C180
C179
C178
C177
C176
C175
C174
C173
C172
C171
C170
C169
C168
C167
C166
C165
C164
C163
C162
C161
C160
C159
C158
C157
C156
C155
C154
C153
C152
C151
C150
C149
C148
C147
C146
C145
C144
C143
C142
C141
C140
C139
C138
C137
C136
C135
C134
C133
C132
C131
C130
C129
C128
C127
C126
C125
C124
C123
C122
C121
C120
C119
C118
C117
C116
C115
C114
C113
C112
C111
C110
C109
C108
C107
C106
C105
C104
C103
C102
C101
C100
C99
C98
C97
C96
C95
C94
C93
C92
C91
C90
C89
C88
C87
C86
C85
C84
C83
C82
C81
C80
C79
C78
C77
C76
C75
C74
C73
C72
C71
C70
C69
C68
C67
C66
C65
C64
C63
C62
C61
C60
C59
C58
C57
C56
C55
C54
C53
C52
C51
C50
C49
C48
C47
C46
C45
C44
C43
C42
C41
C40
C39
C38
C37
C36
C35
C34
C33
C32
C31
C30
C29
C28
C27
C26
C25
C24
C23
C22
C21
C20
C19
C18
C17
C16
C15
C14
C13
C12
C11
C10
C9
C8
C7
C6
C5
C4
C3
C2
C1

